

# 公板功能表

FUNCTION							
	啓動方式	電壓警示	過電流	堵轉保護	正反轉	FG	ALARM
單相 SSOP16	VR	●	●	●		●	
	PWM	●	●	●		●	
SSOP16	I/O	●	●	●	●	●	
	PWM	●	●	●	●	●	
	VR	●	●	●	●		
SOP18	I/O	●	●	●	●	●	●
	PWM	●	●	●	●	●	●
	VR	●	●	●	●	●	●
高速馬達轉速要求		≥ 10000RPM					